

## PAR12X12L

12x 12W LED RGBWAU Parcan with IR Remote

## **USER MANUAL**



### For your safety, please read this user manual carefully before use.

Event Lighting reserves the right to revise the manual at any time. Information and specifications within this manual are subject to change without notice. Event Lighting assumes no liability or responsibility for any errors or omissions. Please contact your local Kookaburra Account Manager.

Version 1.0 (revised F November 2021)

### **Safety Instructions**

#### Warning

- Do not open this device, there are no user serviceable parts inside. Risk of electric shock
- Do not look directly at the light source from close range.
- Avoid contact with the unit during operation, as the housing may become hot. Allow the fixture to cool for at least 15 minutes after turning off before touching.
- Install this device in a location with adequate ventilation, at least 50cm from adjacent surfaces.
- Do not operate this device, or connect this device to power, within 50cm of any flammable material.
- Use a safety chain when mounting this device overhead.
- Do not operate this device outdoors where excessive dust, heat, water, or humidity may affect it.
- Do not operate this device if the housing, lenses, or cables appear damaged.
- Do not connect this device to a dimmer or rheostat.
- Do not operate this device at temperatures higher than 40°C (104°F).
- Only connect this device to a grounded and protected circuit.
- Only use the hanging bracket to carry this device.
- Stop using this device immediately if a serious operating problem becomes apparent.


### Coin/Button Cell Battery Safety Information

This product includes an IR remote that contains a coin/button cell battery. If the battery is swallowed, it can cause severe internal burns and, in extreme cases, can lead to death. Keep batteries away from children.

### **Product Installation**

PAR12X12L can be mounted in many orientations, provided each individual device is secured by the use of the correct mounting bracket. Use a safety chain when mounting PAR12X12L overhead.

## **Dimensions**



# **Lux Chart**

	1m	2m	3m	4m	5m
	Ø0.73	Ø1.46	Ø2.18	Ø2.91	Ø3.64
R	1,445	409	180	93	70
G	2,030	570	250	130	95
В	2,910	882	270	171	126
W	2,420	734	322	171	126
Α	850	258	120	66	46
UV	840	264	120	66	49
FULL	8,550	2,580	1,123	543	423

# **Control Board Operation**

### Menu Map

Menu Map					
Rddr	->	4	-	45 12	Select DMX address
	->		or		Select DMX channel mode (CH-1: 6ch /
					CH-2: 11ch)
SP	->	SP 0	-	SP99	Set program speed
Pr	->	Pr :	-	Pr (3	Select built-in program
SOUR	->	Sou	Sele	ct sound active	e mode
	->		-		Select static colour mode
		i_ i		<u>L</u> 15	(See static colour mode chart below)
Strb	->	5. 88	-	5. 20	Set strobe speed (Hz)
<u> </u>	->		-	-255	Set red colour intensity
	->		-	5255	Set green colour intensity
<u> </u>	->	Ь	-	6255	Set blue colour intensity
<u>                                     </u>	->		-	U255	Set white colour intensity
<u> </u>	->		-	4855	Set amber colour intensity
	->		-	P255	Set UV colour intensity
nodE	->	nodD	-	nod4	Set dimmer speed (nod0: fastest / nod4: slowest)
LEd	->	oFF	or		Toggle LED display on / off
	->	<b>F</b>	Long	g press "Enter"	button to show current temperature
UErn	->		Shov	w current softw	are version
rSEŁ	->		or	YES	Restore settings to factory default

## **Static Colour Mode**

Value	Function
C1	Red
C2	Green
C3	Red+Green
C4	Blue
C5	Blue+Red+UV
C6	Green+Blue
C7	Red +Green+Blue+Amber+UV
C8	White
C9	Red+White
C10	Green+White
C11	Red+Amber
C12	Blue+White+UV
C13	Red + Blue+White+UV
C14	Red + Blue+White
C15	Red+Green+Blue+White+Amber+UV

## **DMX Chart**

### **6 Channel Mode**

Channel	Value	Function
1	000-255	Red: 0% ~ 100%
2	000-255	Green: 0% ~ 100%
3	000-255	Blue: 0% ~ 100%
4	000-255	White: 0% ~ 100%
5	000-255	Amber: 0% ~ 100%
6	000-255	UV: 0% ~ 100%

## 11 Channel Mode

Channel	Value	Function	Note
1	000-255	Master DIMMER 0% ~ 100%	
2	000-255	Red: 0% ~ 100%	
3	000-255	Green: 0% ~ 100%	
4	000-255	Blue: 0% ~ 100%	
5	000-255	White: 0% ~ 100%	
6	000-255	Amber: 0% ~ 100%	
7	000-255	UV: 0% ~ 100%	
8 000-012		Strobe OFF	
	013-255	Strobe (slow-fast)	
	000-009	No Function	
	010-019	Program 1	
	020-029	Program 2	
	030-039	Program 3	
	040-049	Program 4	
	050-059	Program 5	
	060-069	Program 6	
9	070-079	Program 7	
	080-089	Program 8	
	090-099	Program 9	
	100-109	Program 10	
	110-119	Program 11	
	120-129	Program 12	
	130-139	Program 13	
	140-255	Sound active mode	
10	000-255	Speed of auto programs (slow	Ch9 must be set between
		~ fast)	10-139
11	000-255	Colour fade time (jump ~ fade)	Mode must be set to "nod0"

### **IR Remote**

In order to use the IR Remote, PAR12X12L must be in DMX mode without an active DMX connection. If a DMX signal is received, PAR12X12L will prioritise the DMX signal and ignore the IR Remote.

Use **On/Off** to turn PAR12X12L on or off. The current IR settings will be saved automatically when PAR12X12L is powered off and reloaded when it is turned on again. To reset to the factory default Blackout mode, long press **Off.** 

Press **R/G/B/W/A/U** to light up the LEDs in red, green, blue, white, amber or UV respectively. Press a number **0-9** in the orange shaded area to select a pre-set colour.

Press + to increase the intensity of the selected colour and - to decrease the intensity of the selected colour.



Press **Auto/Sound/Strobe** to switch on or off Auto mode, Sound Active mode and Strobe mode, respectively.

Press **Blackout** to clear all the remote settings and blackout PAR12X12L.

## **Technical Specifications**

### **Photometric**

• Light Source: 12x FGW RGBWAU 6-in-1 LEDs

Beam Angle: 40°PWM: 2,000 Hz

• LED Lifespan: 50,000hours

#### **Effects**

Dimming: 0~100%Strobe: 1 - 20 Hz

#### **Power**

Input Voltage: 100~240V AC, 50/60Hz

Power Consumption: 60WConnection: IEC in/out

#### **Control**

• Operation Modes: DMX, manual, auto, sound active, IR remote, master/slave

• DMX channels: 6/11

### Housing

Materials: Die cast aluminium, matte black finish

• Cooling: Fanless Cooling

• Net weight: 1.85kg

## Warranty

Please contact your local Kookaburra Account Manager.