



# GLU DOTS REMOVABLE

## SMALL ADHESIVE DOTS

TECHNICAL SHEET 17/08/2023

### YOUR SMART ADVANTAGES

- Instant bond
- Double-sided
- Acid and lignin free
- Translucent colour

### DESCRIPTION

Bostik Glu Dots Removable are individually formed translucent dots of pressure sensitive adhesive. They are safe, simple to use, acid and lignin free, and non-yellowing.

### RECOMMENDED USES

Ideal for arts & craft, scrap booking, card marking, collages and model making.

Bostik Glu Dots Removable are the perfect size to allow for precise and accurate placing of small objects such as sequins, beads, rhinestones, wiggly eyes and many other craft embellishments.

Bostik Glu Dots Removable stick to almost anything, including paper, wood, plastic, metal and glass.

### PRODUCT CHARACTERISTICS

|                         |                      |
|-------------------------|----------------------|
| <b>Composition</b>      | Hydrocarbon Polymer  |
| <b>Colour</b>           | Transparent          |
| <b>Form</b>             | Sticky adhesive dots |
| <b>Specific Gravity</b> | 1.0 approx.          |
| <b>Pack Quantity</b>    | 64 dots              |



### DIRECTIONS FOR USE

Read and understand the Safety Data Sheet before using this product. SDS can be acquired by visiting [www.bostik.com/australia](http://www.bostik.com/australia).

Always test Bostik Glu Dots Removable on an unseen area of your materials prior to application.

Not suitable for use on damp, delicate, absorbent or newly decorated surfaces. Not recommended for application to painted plaster walls.

Recommendations and suggestions are for guidance only, since conditions of use are out of our control.

### SURFACE PREPARATION

1. Ensure surfaces are clean; dry free from grease and loose materials.
2. For best results, surfaces and surroundings should be pleasantly warm.
3. Take out a sheet of dots from the wallet.
4. Fold and then tear off, along the perforations, to remove as many dots as required.

## APPLICATION

5. Peel off the printed release paper to reveal a Glu Dot left on the clear backing. The Glu Dot is now ready for use.
6. Press the Glu Dot firmly onto the item to be bonded and then slowly and carefully peel off the clear backing.
7. The Glu Dot will be adhered to the item, which can now be bonded to the other surface.

## CLEANING

Carefully and very slowly peel away. As the adhesive gets stronger with time, it is recommended that the dots are removed by carefully rubbing and rolling them off the surface.

## SHELF LIFE & STORAGE

24 months, unopened, from date of manufacture. Store in dry conditions between +5° C and +25° C

## SAFETY

Always read the Technical Data Sheet and Safety Data Sheet (SDS) before handling or use. Full product safety information required for safe use is not included in this data sheet. SDS available by request or at [www.bostik.com.au](http://www.bostik.com.au)

### DISCLAIMER

Bostik offers this Technical Data Sheet ("TDS") for descriptive and informational use only. It is not a warranty, a contract or a substitute for expert or professional advice. Please also see the local product Safety Data Sheet for health and safety considerations.

The statements, technical information, data, and recommendations contained in this TDS are provided 'AS IS' and are not warranted or guaranteed in any way. They represent typical results for the products and are based on Bostik's research only. Since the conditions and methods of use of the products are beyond our control, Bostik expressly disclaims any and all liability and damages of whatever kind or nature that may arise from any use of the products, the results therefrom, or reliance on the information contain herein.